

Remove hazard warning triangle, refer to Owner's Manual.

Remove floor mat (1).

Unfasten screws (2) and expanding rivets (3) and lift off finisher strip.

If necessary, unfasten screws (4).

